

# INDEX

<b>A</b>	
ACCELERATOR PEDAL	42
ACCELERATOR PEDAL MOUNTING BOLT	42 & 43
ACCELERATOR PEDAL ROD SEAL	13
ACCELERATOR RETURN SPRING	129
ACCELERATOR RETURN SPRING BRACKET	129
ACCELERATOR RODS	129
ACCELERATOR SHAFT TO THROTTLE ROD CLIP	43 & 129
ACORN NUT	43
AIR CLEANER ELEMENTS	130
AIR CLEANER WING NUTS	68 & 130
AIR CONDITIONER BLOWER SWITCH	110
AIR COND CHROME REGISTER	81
AIR COND REGISTER CLIP	43 & 81
AIR CONDITIONING DRIER	130
ALTERNATOR ADJUSTMENT ARM BRACKET	130
ANTENNA BASE RUBBER GASKET	13
ANTENNA FRONT FENDER MOUNT	68
ARMREST OVERLAY	81
ARMRESTS: 1964 XL	81
ASHTRAY RECEPTACLE BUMPER	13
ASHTRAY: CONVERTIBLE REAR	82
ASHTRAY SLIDING COVER REAR SEAT CONVERTIBLE	82
<b>B</b>	
BACK GLASS WEATHERSTRIP	13
BACK-UP LIGHT SWITCH	110 & 118
BALL JOINT KITS: UPPER AND LOWER	130
BATTERY CABLE SETS	131
BATTERY HOLD DOWN CLAMP	131
BATTERY HD CLAMP BOLT & NUT	131
BATTERY TRAYS	131
BELTLINE INNER WHISKER TYPE	16
BELTLINE OUTSIDE RUBBER TYPE	16
BODY TO FRAME MOUNTING PAD KIT	14
BOOKS AND MANUALS	181 – 184
BOOK: "HOW TO RESTORE YOUR MUSCLE CAR"	185 – 186
BRAKE AND CLUTCH PEDAL PADS	42
BRAKE BOOSTER TO FIREWALL BOOT	10
BRAKE DRUMS: Front & Rear	131 & 132
BRAKE FRONT WHEEL CYLINDERS	133
BRAKE HOSES: Front & Rear	133
BRAKE HOSE RETAINING CLIP	44
BRAKE LINES	134
BRAKE LINE CLIPS	44
BRAKE MASTER CYLINDER	132
MASTER CYLINDER CAP W/ GASKET	132
BRAKE MASTER CYLINDER BOOT	14
BRAKE REAR WHEEL CYLINDERS	133
POWER BRAKE BOOSTER	132

BRAKE/CLUTCH PEDAL MOUNTING BRACKET BUSHING	123
BUMPER (REAR) STONE DEFLECTOR	15
BUMPER STONE DEFLECTOR CLIP	44
BUMPER BOLTS	109
BUMPER GUARD RUBBER TIPS	14 & 109
BUMPER WAVE WASHER	109

<b>C</b>	
CARBURETOR HOLD DOWN NUTS	135
CARBURETOR TO AIR CLEANER GASKET	129
CARBURETOR LINKAGE KITS	135
CARPET SETS	76
CARPET SET: RUBBER	76
CENTER LINK	135
CHOKE HEAT CHAMBER ASSEMBLY	135
CHOKE OUTLET TUBE INSULATION	68 & 135
CIRCUIT BREAKERS	110
CIRCUIT BREAKER MOUNTING BRACKET	110
CLUTCH CROSS SHAFT	121 & 122
CLUTCH DISC	121 & 136
CLUTCH FORK	122 & 137
CLUTCH FORK ADJUSTING ROD	121 & 136
CLUTCH FORK RETRACTING SPRING	121 & 136
CLUTCH FORK RELEASE SPRING BRACKET	120 & 137
CLUTCH FORK RUBBER BOOT	15 & 122
CLUTCH PEDAL ROD BUSHING	121
CLUTCH PEDAL ROD SEAL	15
CLUTCH RELEASE EQ SHAFT BALL	122
CLUTCH RELEASE EQ SHAFT FELT WASHERS	123
CLUTCH RELEASE EQLZR BAR 427	121 & 136
CLUTCH RELEASE EQLZR BAR 406-390-352	122 & 137
CLUTCH RELEASE LEVER ANTI-RATTLE SPRING	122 & 137
CLUTCH RELEASE LEVER ASSEMBLY	122 & 137
COAT HOOKS	82
COIL	137
COIL MOUNTING BRACKET	137
COIL SPRING TOP INSULATOR	27
COLUMN SHIFT INDICATOR DIAL BEZEL	82
COLUMN SHIFT LEVER SOCKET	82 & 120
CONSOLE GLOVE BOX DOOR BUMPERS	20
CONSOLE GLOVE BOX DOOR STRIKER	44 & 83
CONSOLE GLOVE BOX LINER	83
CONSOLE GLOVE BOX DOOR OVERLAY	83
CONTROL ARM BUMPERS	15
LOWER CONTROL ARM SHAFT BUSHINGS	155

CONV BOOT SEAT BACK STUD	45
CONV PISTON COVERS	83 & 138
CONV TOP BOOT ATTACHING STUD	44
CONV TOP BOOT STUD RETAINER	45
CONV TOP HEADER BOW W/STRIP	26
CONV ROOFRAIL WS MNTG BOLT	26 & 45
CONV SIDE TRIM PANEL STUD	45
CONV TOP HYDR MOTOR & PUMP	138
CONV TOP HYDRALIC HOSE ASM	138
CONVERTIBLE TOP CABLES	138
CONVERTIBLE TOP CYLINDERS	138
COUNTRY SQUIRE SIDE RAIL CLIP	62 & 67
COURTESY LAMP BRACKET	83
COURTESY / MAP LIGHT DOOR SWITCH	111
CRTSY LAMP SOCKET/WIRING ASM	83 & 111
COWL TOP GRILLE ATTACHING SCREWS	46
COWL WIRING HARNESS CLIP	46
CRANKCASE VENT SYSTEM ASM	139
CRANKCASE VENT ADAPTER	139
CRANKSHAFT HARMONIC BALANCER	139

<b>D</b>	
DASH BEZELS	84
DASH PAD OVERLAY	84
DASH PAD RETAINING CLIP	46
DECALS: Engine Compartment Kit & Trunk Kit	174
DECALS	175 - 177
DEFROSTER HOSE NOZZLE CLIP	46
DIFFERENTIAL CARRIER COPPER WASHER AND LOCK NUT	46, 47, & 139
DIFFERENTIAL HOUSING GASKET	139
DIPSTICK TUBE: Big Blocks	140
DISTRIBUTOR CAP	140
DISTRIBUTOR GASKET	16
DISTRIBUTOR PRIMARY WIRE	140
DISTRIBUTOR VACUUM LINES	140
DOME LIGHT LENSE	102
DOME LIGHT LENSE BEZEL	102
DOOR ACCTUATING BARREL SLEEVE	47
DOOR & TAILGATE DRAIN SEAL	17
DOOR BUMPERS	16
DOOR CRTSY LIGHT LENSE WHITE	102
DOOR HANDLE RUBBER PADS	18
DOOR HANDLES: INSIDE	88 & 99
DOOR HANDLES: OUTSIDE	98
DOOR INSIDE HANDLE ESCUTCHEON	88
DOOR HANDLE OUTSIDE FINISH PLATES	98
DOOR HINGE PIN & BUSHING SET	47, 86 & 141
DOOR & IGNITION LOCK CYLINDER & KEY SET	107
DOOR LATCH SCREWS	47
DOOR LOCK BUTTON GROMMET	86
DOOR LOCK KNOBS	86
DOOR LOCK STRIKER PLATE & SHIM	98 & 140
DOOR LOCK STRIKER SCREWS	47
DOOR LOWER JAMB BUMPERS	16
DOOR PANEL RETAINING CLIPS	48
DOOR SILL PLATES	77 & 87
DOOR SILL PLATE DECAL	87
DOOR WEATHERSTRIP	17

DOOR / WINDOW REGULATOR ARM ROLLER ASSEMBLY	48 & 86
DOOR / WINDOW REGULATOR HANDLE RETAINER	48 & 101

<b>E</b>	
EMERGENCY BRAKE PEDAL PAD	42
EMERGENCY BRAKE CABLE: Front & Rear	134
EMERGENCY BRAKE EQUALIZER ROD	134
ENGINE / TRUNK LIGHT KIT	68
ENGINE WIRING VALVE COVER CLIP	55
EXHAUST MANIFOLD BOLT LOCKING TABS	48, 49 & 141
EXHAUST MANIFOLD BOLT SETS	49 & 141
EXH THERMOSTAT CONTROL VALVE	141

<b>F</b>	
FENDER BOLT	49
FENDER BOLT J-CLIP	49
FENDER TO COWL SIDE RETAINER BOLT & CLIP	50
FENDER EAGLE BARREL CLIPS	50 & 96
FENDER EAGLES: 427-406-390	96
FENDER SKIRT MOUNTING PINS	69
FENDER SKIRT RUBBER SEAL	18
FENDER TOP ORNAMENTS 1963 & 64	69 & 96
FIREWALL HEATER DELETE COVER PLATE	72 & 141
FIREWALL INSULATION PAD	50, 77, & 88
FIREWALL PAD RETAINING CLIP	50
FLAT HEAD 8X3/8 ATTACHING SCREW	50
FLOOR PLUGS	23
FLYWHEEL AND RING GEAR	142
FRAME, BODY, CORE SUPPORT CHASSIS BOLT	50
FR STABILIZER BAR END REPAIR KIT	28 & 157
FR SUS COIL SPRING TOP INSULATOR	27
FRONT DOOR INNER SEAL	17
FRONT FENDER SPLASH SHIELD	18
FUEL & BRAKE LINE COMBO CLIP	51 & 145
FUEL (GAS) DOOR RUBBER BUMPER	18
FUEL FILTER BOWL	142
FUEL FILTER BRACKET	145
FUEL FILTER CANISTER	145

FUEL FILTER ELEMENT	146
FUEL LINE CLAMP	145
FUEL LINE FLEX HOSE	145
FUEL LINES	144
FUEL LOG FITTING	51 & 143
FUEL LOGS	143
FUEL PUMP	142
FUEL PUMP FITTING CONNECTOR	51 & 142
FUEL PUMP FILTER BOWL GASKET	146
FUEL TANK FILLER CAP	145
FUEL TANK SEND UNIT LOCKING RING	112 & 143
FUEL TANK SENDING UNIT FLOAT	111 & 143
FUEL TANK SENDING UNIT GASKET	18, 111 & 143
FUEL TANK SENDING UNIT TUBE FILTER	111 & 143
FUEL TANK SENDING UNIT	111 & 142
FUEL & TEMP GAUGE BEZELS	85

<b>G</b>	
GAS HOSE	146
GAS TANK STRAP	146
GAS TANK STRAP BOLT	146
GEAR SHIFT LEVER INSULATOR	18 & 120
GEAR SHIFT LEVER TRUNION	120
GEAR SHIFT LEVER TRUNION SPRING	120
GEAR SHIFT SELECTOR ARM BUSHING	120
GENERATOR ADJ ARM BRACKET	146
GENERATOR PULLEY	146
GENERATOR RUBBER DUST SHIELD	19
GLASS RUN CHANNEL FOR FR DOOR	19
GLASS RUN CHANNEL FRONT/REAR DOOR LOCK SIDE	19 & 20
GLASS RUN CHANNEL LINER	19
GLOVE BOX DOOR RUBBER BUMPER	20
GLOVE BOX EMBLEM 500	88
GLOVE BOX LINERS	89
GLOVE BOX LIGHT ASM & SWITCH	89 & 112
GLOVE BOX, INSTRUMENT PANEL DOOR CATCH	89
GRILLE EMBLEM INSERTS	97
GROUND STRAP ENGINE TO FIREWALL	147
<b>H</b>	
HASH MARK BARREL CLIPS	53
HEADLIGHT BULBS	102
HEADLIGHT DIMMER SWITCH PIGTAIL CONNECTOR	112 & 147
HEADLIGHT DIMMER SWITCH	112
HEADLIGHT KNOB AND SHAFT	89
HEADLIGHT SWITCH	112
HEADLINER	77
HEATER AIR INLET DUCT CONNECTOR	20
HEATER BLOWER MOTOR	147
HEATER BOX (PLENUM) SEAL KIT	148
HEATER CORE ASSEMBLY	147
HEATER CORE INSULATION & ANTI-RATTLE KIT	20 & 147
HEATER CORE TUBE GROMMETS	21 & 147
HEATER HOSE	148
HEATER HOSE OUTLET ELBOW	148
HEATER HOSE TO FENDER CLAMP	51 & 148
HEATER HOSE, A/C HOSES & WIRING LOOM 7" ALUMINUM STRAP	68
HEATER PLENUM HOSE	148
HEATER PLENUM SEAL KIT	21
HEATER RESISTOR	113
HOOD ADJUSTMENT BUMPER CAP	21
HOOD BUMPERS	21
HOOD HINGE SPRINGS	73 & 149
HOOD LETTERS	97
HOOD LETTER BARREL CLIPS	52
HOOD ORNAMENT 1964	97
HOOD REAR TO FENDER BUMPER	21
HOOD REAR WEATHERSTRIP	22
HOOD FRONT SEAL WEATHERSTRIP	21
HOOD PAD INSULATION	71 & 149
HORNS	113
HORN BRUSH REPAIR KIT	89 & 113
HORN: RETAINER, SPRING, SCREWS & INSULATOR	88 & 89

HORN RING CENTER INSERT	90
HORN RING CENTER RETAINER	90
HORN RELAYS	113
HOSE CLAMP KITS	70 & 149
HUB (FR) ASSEMBLY GREASE CAP	149

<b>I</b>	
ID PLATES, INSTRUCTION CARDS AND WINDOW STICKERS	178-180
IDLER ARM BUSHINGS	149
IDLER ARM KIT	149
IGNITION SWITCH	113
IGNITION SWITCH BEZEL	84 & 107
IGNITION SWITCH PIGTAIL	113
IGNITION SWITCH LOCK CYLINDER AND KEYS	107
INNER A-FRAME SPLASH GUARDS	22
INNER FENDER (APRON) SEALS	22
INNER RIGHT FRONT FENDER TO FRAME SEAL	22
INSIDE WINDOW REGULATOR HANDLE SPRING	95 & 100
INSTRUMENT CLUSTER VOLTAGE REGULATOR	115 & 150
INSTRUMENT PANEL CENTER PLASTIC COVER	85
INTAKE MANIFOLD (ALUMINUM) BOLT AND WASHER	150
INTERIOR GARNISH MOULDING AND TRIM SCREWS	52

<b>K</b>	
KEY BLANKS	107
KICK PANELS	91

<b>L</b>	
LICENSE PLATE BODY & SOCKET ASSEMBLY	103
LICENSE PLATE BUMPER	22
LICENSE PLATE FRAMES	70
LICENSE PLATE LAMP LENSE GASKET	103
LICENSE PLATE LIGHT LENSE	103
LICENSE PLATE LIGHT LENSE DOOR LIGHTERS	103
LOWER CONTROL ARM OFFSET SHAFT RETAINER BOLT	91
LUG NUTS (WHEEL)	142
	52 & 150

<b>M</b>	
MANUALS AND BOOKS	181-184
MASTER CYLINDER CAP	69 & 132
MASTER CYLINDER PUSH ROD BUSHINGS	132
MIRRORS: INSIDE	74
MIRRORS: OUTSIDE	75
MIRROR CREST PLASTIC	75 & 97
MIRROR BRACKETS	74
MOTOR MOUNTS	150
MOULDING CLIPS: 1963	57-62
MOULDING CLIPS: 1964	63-67
MUFFLER HANGER INSULATOR REPAIR STRAP	22 & 151

<b>N</b>	
NEUTRAL SAFETY SWITCH	114
<b>O</b>	
OFFSET SHAFT LOWER FR SUSPN	155
OFFSET SHAFT RETAINER BOLT & BUSHING	155
OIL DIPSTICK: 260 / 289	151
OIL FILLER CAP	69 & 151
OIL FILTERS	70, 151 & 152
OIL PRESSURE SENDING SWITCH	114
ORDER FORMS	195 - 198
OVERDRIVE KICKDOWN SWITCH	114

<b>P</b>	
PACKAGE TRAY TRIM PANEL	78 & 91
PAINT:	
ENGINE PAINT	168
CORRECT ENGINE COLORS	169 & 170
DETAIL PAINTS	171
ENGINE COMPARTMENT PAINT	172
RUST PREVENTATIVE PAINT	173
PARKING BRAKE CABLE TO CONTROL ASSEMBLY RETAINING CLIP	52
PARKING LIGHT BLUBS AMBER	104
PARKING LIGHT LENSE GASKET	104
PARKING LIGHT LENSES	104
PARKING LAMP LENSE MNTG SCREW	52 & 104
PARKING LAMP WIRING CLIP	53
PCV CRANKCASE VENT REGULATOR VALVE ASSEMBLY	152
PCV INTAKE ELBOW FITTING	53 & 152
PEDAL PADS	42
PINION SEAL	152
PLASTIC MOUNTING BUTTONS	22
PLUGS: FLOOR PAN / TRUNK	23
POWER STEERING PARTS	124-127
PS CONTROL VALVE	125
PS CYLINDER	125
PS PUMP	126
PS HOSES	125 & 126
PS TO MANUAL STEERING CONVERSION	127 & 152
PS WINDOW MOTOR DRIVE COUPLER	161
POWER WINDOW REGULATOR DRIVE KIT	161

<b>R</b>	
RADIATOR AIR DEFLECTOR SEAL	23 & 24
RADIATOR CAP	69 & 153
RADIATOR CORE SUPPORT SHIMS	24 & 153
RADIATOR CORE SUPPORT TO FRAME MOUNTING PADS	24 & 153
RADIATOR CORE SUPPORT TO FRAME SPLASH SHIELDS	24
RADIATOR HOSES	153
RADIATOR SUPPLY TANK OVERFLOW HOSE J-CLIP	53 & 154
RADIATOR SUPPLY/OVERFLOW TANK	154
RADIATOR SUPPORT PADS	24 & 25
RADIO KNOB SET	70 & 91
REAR BRAKE SHOE HOLD DOWN KIT	133
REAR QUARTER PANEL EMBLEM INSERT XL	98
REAR QTR WINDOW ESCUTCHEON	100
REAR QTR WINDOW LOWER CORNER SEAL	25
REAR ROLLUP WINDOW W/STRIP	25
REAR SIDE QTR GLASS W/STRIP STATION WAGON	25
REAR SPRING CENTER MOUNTING INSULATOR	27
REAR SPRING HANGER BUSHINGS: FRONT AND REAR	27
REAR SPRING ANTI-SQUEEK PAD	27
REAR SPRING SHACKLE KITS	157
REGULATOR VOLTAGE	114 & 154
RIGHT ANGLE ELEC CONNECTOR PLUG AND LEAD	114 & 154
ROAD DRAFT TUBE	154
ROCKER PANEL DRAIN VALVE	25
ROOFRAIL WEATHERSTRIP	26

S	
SCREW PROTECTORS FOR CORE SUPPORT	45
SEAT BACK BUTTONS	78, 79 & 92
SEAT BACK STOP	78 & 91
SEAT BELTS	80 & 93
SEAT PIPING	79
SEAT TRACK ADJUSTING HANDLE	78 & 91
SHACKLE KITS REAR SPRING	157
SHAFT KITS UPPER	155
SHAFT BUSHING KIT LOWER FR SUS	155
SHAFT OFFSET – LOWER FR SUSPN	155
SHIFT BOOTS & BEZEL 4-SPEED	118 & 119
SHIFT BOOT AUTOMATIC 1964	118
SHIFT KNOBS	119
SHOCK ABSORBER MOUNTING REPAIR KIT	26 & 156
SHOCK ABSORBERS	156
SHOCKS - REAR AIR	156
SIDE ROOF ORNAMENT BEZEL	97
SIDE ROOF ORNAMENT INSERT	97
SIDE SCRIPT BARREL CLIP	53
SPARE TIRE HOLD DOWN BOLT	93 & 156
SPARK PLUG WIRE SEPARATORS	156
SPEEDOMETER BEZELS	85
SPEEDOMETER LENSE	85 & 104
SPEEDOMETER CABLE CASING & CORE	157
SPEEDO GEAR RETAINING CLIP	54 & 157
SPRING CLAMPS REAR	157
SPRING NUT CAP HEATER	54
STABILIZER BAR END REPAIR KIT	28 & 157
STABILIZER BAR BUSHINGS	28
STARTER CABLE TO RIGHT HAND INNER FENDER CLIP	54
STARTER SOLENOID	114 & 158
STEERING BOX	158
STEERING BOX PITTMAN ARM SHAFT OIL SEAL	158
STEERING BOX SECTOR SHAFT BUSHING	158
STEERING COLUMN FIREWALL GROMMET	28
STEERING INSULATOR COUPLING BOLT	54 & 158
STEERING WHEEL RETAINING NUT	54
STOPLIGHT SWITCH ASSEMBLY	115
SUNVISOR ANCHOR PIN RUBBER TIP	28
SUNVISOR BRACKETS	70 & 93

T	
TAIL LAMP ASSEMBLY TO BODY SEAL	29 & 106
TAIL LIGHT BEZEL	71 & 105
TAIL LIGHT LENSE	104
TAIL LIGHT LENSE GASKET	105
TAIL LIGHT LENSE MOUNTING SCREW	54 & 105
TAIL LIGHT RING RUBBER GASKET	28 & 105
TAIL LIGHT WIRING TO LEFT REAR INNER FENDER CLIP	54
TEMPERATURE GAUGE 1963	115
TIE ROD ADJUSTING SLEEVE	159
TIE RODS	159
TIE ROD OR CENTER LINK RUBBER DUST BOOT	29
TIMING POINTER 427	159
TIRE VALVE STEM EXTENSIONS	71
TOE-IN STABILIZER BAR	159
TRANSMISSION MOUNT	151
TRANSISTOR IGNITION AMPLIFIER	115 & 159
TRANSISTORIZED IGNITION CURRENT RELAY	115
TRANSMISSION 4-SPEED LOWER MECHANISM	123 & 160
TRANSMISSION 4-SPEED SHIFT LEVERS	123 & 160
TRANSMISSION COOLER LINES	160
TRUNK DECAL KIT	174
TRUNK FLOOR EXTENSION DRAINS	29
TRUNK LETTERS	98
TRUNK LETTER BARREL CLIPS	55
TRUNK LID BUMPER	29
TRUNK LOCK OPERATING LEVER 1964	108
TRUNK / ENGINE LIGHT KIT	71
TRUNK LIP MOULDING	94
TRUNK LIP EXTENSION MOULDING	94
TRUNK LOCK BEZEL GASKET	29
TRUNK LOCK CYLINDER & KEYS 1964	108
TRUNK MAT 63 AND 64	94
TRUNK RELEASE REMOTE CONTROL	71
TRUNK SIDE PANEL BOARDS	94
TRUNK SIDE PANEL BOARD MOUNTING SCREWS	55
TRUNK WEATHERSTRIP	29
TURN SIGNAL LEVER	93
TURN SIGNAL SWITCH	115

<b>V</b>	
VALVE COVER BOLT SET	55
VALVE COVER GASKET	160
VENT WINDOW ADJ OPENING SEAL	30
VENT WINDOW FRAME TOP BUMPER	31
VENT WINDOW VERT DIV BAR WS	30 & 31
VENT WINDOW WEATHERSTRIP	30 & 31
VOLTAGE REGULATOR / HORN RELAY MOUNTING SCREW	55

<b>W</b>	
WATER PUMP	160
WATER PUMP BY-PASS HOSE	160
WATER TEMP SENDING SWITCH	115
WHEEL BEARING NUT RETAINER	161
WHEEL COVER SPINNER INSERTS	72
WHEEL LUG NUTS	56 & 161
WHEEL LUG WRENCH & JACK HANDLE	101 & 161
WINDLACE	80
WINDLACE INSTALLATION CLIP	56 & 80
WINDLACE PINCH WELD	79
WINDOW POWER MOTOR DOOR COUPLER	32 & 116
WINDOW REG HANDLE WASHER	95 & 100
WINDOW INSIDE REGULATOR HANDLE SPRING	95 & 100
WINDOW (ELEC) REGULATOR RELAY	115
WINDOW (POWER) SWITCHES	116
WINDOW POWER MASTER SWITCH SHIELD	95 & 116
WINDOW REAR QTR ESCUTCHEON	95
WINDOW STICKERS, INSTRUCTION CARDS AND ID PLATES	178-180
WINDOW WHISKERS (FUZZIES) INNER AND OUTER BELTLINE WS	16
WINDSHIELD WEATHERSTRIP	31
WINDSHIELD FINISH STRIP WELT	31
WINDSHIELD PILLAR GARNISH FILLER	32
WINDSHIELD PILLAR WEATHERSTRIP	32
WINDSHIELD WASHER HOSE SET	72
WINDSHIELD WASHER PUMP ASM	72
WINDSHIELD WASHER RES CAP	73
WINDSHIELD WASHER RESERVOIR ASSEMBLY WITH CAP	73
WINDSHIELD WASHER RESERVOIR MOUNTING BRACKET	73
WINDSHIELD WIPER CONTROL KNOB	95
WINDSHIELD WIPER CONNECTOR ARM CLIP	56
WIRING HARNESSES	116 & 117
WIRING HARNESS STRAP	56 & 73